

## **INSTALLING A LOCK NUT ON OVEN RACK LIFT BRACKETS**

### **TOOLS REQUIRED:**

**RACHET WRENCH WITH 7/16" SOCKET**

**5/32" ALLEN WRENCH, LONG HANDLE**

**ANTI-SIEZE COMPOUND**

- 1. REMOVE THE S.S. NUTS FROM THE 1/4" S.S. FLAT SOCKET SCREW WHICH HOLDS THE S.S. LIFT DEVICE ON TO THE OVEN RACK.**
- 2. APPLY THE ANTI-SIEZE COMOUND TO THE S.S. BOLT THREADS.**
- 3. INSTALL THE 1/4" S.S. LOCK NUT, THIS WILL NOT GO ON EASY.**
- 4. WIPE OFF ANY EXCESS ANTI-SIEZE COMPOUND FROM AROUND NUT.**