



T-BAR WALL SHELF

INSTALLATION INSTRUCTIONS:  
 DRILL DESIRED NUMBER OF MOUNTING HOLES IN 1 1/2" X 1 1/2" REAR ANGLE  
 TO ALIGN WITH WALL STUDS. MOUNT SHELVING TO WALL WITH FASTENING DEVICES  
 THAT ARE SUITABLE FOR WALL SURFACE AND ARE LARGE ENOUGH TO SUPPORT  
 THE DESIRED LOAD.