

Modular Equipment Stand

Assembly Instructions

Parts List

Top Shelf
Removable top
U-Brace
Posts (4)
Allen wrench

Optional

Undershelf
Casters (4)

1. Lay top shelf at right angle to floor.
(The top of the shelf is the side that is flush.)
Position first post into corner bracket flush with top of shelf.
Tighten set screw.
2. Repeat step 1 with the U-Brace. Open side faces front.
If casters ordered set U-Brace at bottom of post.
If casters not ordered set U-Brace according to local code.
3. Repeat steps 1 and 2 with remaining posts.

Optional Undershelf

Set Undershelf on U-Brace.

Optional Casters

Remove plastic caps from bottom of posts.
Insert stem of caster into bottom of post until stem is no longer showing.

5. Set equipment stand upright and attach top sheet.

